


# **BOMAX**®

## **BMCC-140 PARTS LIST**



Ver.01 2015



Ref No.	Parts No.	Description	QTY	Price/unit
1	CC140-001	water tank cap	1	
2	CC140-002	water tank	1	
3	CC140-003	water tank bracket	1	
4	CC140-004	rubber cover	2	
5	CC140-005	push handle	1	
6	CC140-006	adjust wheel	1	
7	CC140-007	bearing pedestal FL203	1	
8	CC140-008	screw bar	1	
9	CC140-009	rubber cover position pin	2	
10	CC140-010	handle postion pin	2	
11	CC140-011	stop switch	1	
12	CC140-012	handle basement	1	
13	CC140-013	rubber protect cover	1	
14	CC140-014	water pipe quick connecter	1	
15	CC140-015	adjust guide	1	
16	CC140-016	belt cover	1	
17	CC140-017	basement	1	
18	CC140-018	pulley	1	
19	CC140-019	engine pulley	1	
20	CC140-020	belt	2	
21	CC140-021	wheel bearing pedestal P203	2	
22	CC140-022	rear wheel	2	
23	CC140-023	screw bolt	1	
24	CC140-024	rear shaft	1	

Ref No.	Parts No.	Description	QTY	Price/unit
25	CC140-025	front wheel	2	
26	CC140-026	adjust plate	1	
27	CC140-027	blades shaft	1	
28	CC140-028	M8 bolt	4	
29	CC140-029	blade clamp	1	
30	CC140-030	nut for blade shaft	1	
31	CC140-031	bearing pedestal P206	2	
32	CC140-032	cut depth guide	1	
33	CC140-033	water pipe mouting plate	1	
34	CC140-034	water connector	1	
35	CC140-035	tee joint	1	
36	CC140-036	water pipe distributor	1	
37	CC140-037	pipe connector	1	
38	CC140-038	water valve	1	
39	CC140-039	water pipe	1	
40	CC140-040	engine	1	
41	CC140-041	guide wheel	1	
42	CC140-042	cut guide	1	
43	CC140-043	blade cover	1	
44	CC140-044	blade cover bolt	1	
45	CC140-045	5X18 keyway adjust wheel	1	
46	CC140-046	5X27 keyway engine pulley	1	
47	CC140-047	6X11 keyway main shaft pulley	1	